

Advantages at a glance

The wind sensor pair PRO-WEA 0...10 V for determination of wind direction and wind speed was specially developed for use on wind power plants.

- ▶ Nonimpact measuring principle "Magnetical Positioning Encoder System" (MPES)
 - ✓ for precise data acquisition
- ▶ Measuring elements with double supported ball bearing of the axis of rotation
 - ✓ for lower friction and abrasion and high reliability and longevity
- ▶ Stably wind vane and fail-safe 3-armed cup anemometer made of seawater resistant aluminium
 - ✓ for highest capacity
- ▶ Simple installation principles for mast, flange and bore
 - ✓ for high flexibility
- ▶ Sensors with cable-plug connection or assembled cable
 - ✓ to afford advantages at commissioning or other services
- ▶ Aerodynamical design
 - ✓ for precise and safe measurements

Descriptions

You benefit from our more than 25 year long experience in the development and manufacture of wind sensors for renewable energy!

- Improved protection against electrostatic discharge for operation in lightning-prone regions
- Wide range of operating for all-year application in most climatic zones due to integrated, regulated heating
- Especially robust due to reinforced axis
- Very high measuring range of 60 m/s
- Low starting values of < 0.5 m/s
- High resolution of measuring values
- Simple installation and maintenance through cable-plug connection and single screw attachment
- Very low needs of maintenance
- Optional special high UV-resistant cable



Please note the loss of warranty and non-liability by unauthorised manipulation of the system. You need a written permission of the LAMBRECHT meteo GmbH for changes of system components. These activities must be operated by a qualified technician.

The warranty does not cover:

1. Mechanical damages caused by external impacts (e. g. icefall, rockfall, vandalism).
2. Impacts or damages caused by over-voltages or electromagnetic fields which are beyond the standards and specifications in the technical data.
3. Damages caused by improper handling, e. g. by wrong tools, incorrect installation, incorrect electrical installation (false polarity) etc.
4. Damages which are caused by using the device beyond the specified operation conditions.

Initial operation

The wind can be represented by a vector quantity. For a complete description of the wind it is necessary to specify its speed and direction. The two components are subject to spatial and temporal variations; thus, strictly speaking, they are valid only for the site where the measuring instrument is put up. We therefore recommend to select the place of installation very carefully.

Selecting the place of installation

Generally, wind measuring instruments should not measure the specific wind conditions of a limited area, but indicate the typical wind conditions of a wider area. The values measured at different places must be comparable.

Thus, when installing the sensor you should make sure the place of installation is not under the lee of great obstacles. The distance between the obstacles and the sensor should be 10 times the height of the obstacles (this corresponds to the definition of an undisturbed terrain).

If an undisturbed terrain of this kind does not exist the sensor must be put up at a height of at least 5 m above the obstacle height.



If the sensor must be installed on a roof top the place of installation must be in the middle of the roof to avoid predominant wind directions.

If you want to measure both wind direction and wind speed, install the sensors at the same measuring point, if possible, and make sure to avoid any mutual influence of the sensors.

A wind sensor pair easily meets this requirement since the sensors are set up side by side. Their horizontal distance should be approximately 1.5 m. The two sensors must be staggered vertically so that the lower edge of the upper wind speed sensor is 0.1 to 0.5 m above the upper edge of the lower wind direction sensor.

Mounting of the cup rotor and the wind vane at the sensor

The bores at the cup rotor and the wind vane are attached in such a way that they can only be installed in a certain clear position. All 3 screws must be used to fasten the cup rotor resp. the wind vane. Thus the correct direction of rotation is guaranteed. The necessary wrench is included in delivery.



Maintenance

The sensor design permits long periods of maintenance-free operation.

We recommend a regular visual verification and functional test of the wind sensors as well as a sensor calibration of both sensor types at intervals of 2 years.

With problems, which you cannot solve, do not hesitate to contact our LAMBRECHT service under:



Tel.: +49-(0)551-4958-0

Fax: +49-(0)551-4958-327

e-mail: support@lambrecht.net



Dimensional drawings





Principles of installation



Attention!

Because the installation take place in a dangerous height, the assembly personal must follow the rules for prevention of accidents.



Make sure the device is easily accessible so that you can set up the north direction for the wind direction sensor and perform any maintenance work. To reach the sensors use a ladder of the appropriate length or a telescoping working platform of the appropriate height.



Ladders or other lifting helps must be absolutely in order and must be guarantee a secure support! Follow the rules for prevention of accidents.

I. Traverse with slotted bores

(Id-no.: 32.14567.010 000)

At the traverse at each end are bores with a slot and with a \varnothing 30 mm.

1. Remove the nut from the sensor.
2. Put a sensor with assembled cable sidewise into the bore.
3. Attach the sensor with the flat side of detached nut from the lower side. Tighten with a suitable tool (wrench size 40), until a twisting safety of the sensor aligned to the north is given.

II. Mounting into bores

Material thickness for installation of the sensor between the nuts may be max. 10 mm.

1. Remove the thread nut from the sensor.
2. The sensor with cable-plug connection is led without cable into the bore and fastened by the opposite side with the loose nut as under I.3.



When you install the connecting cables make sure not to excessively shorten the cable leading to the connector in the lower part of the sensor casing so that you can later maintain or dismantling the sensor. Put further a cable loop as sensor protection against water under the sensor.



Tip: Install the sensors on ground to the traverse and align you the wind vane parallel to the traverse. You go only then upward, in order to accordingly align the sensors with traverse under assistance of a partner on ground.

Setting up the North Direction for the Wind Vane

For wind direction measurements the north mark on the sensor must be aligned with the geographical north direction.

You have to turn the marking exactly over the marking at the sensor shaft. When you have aligned the marks, you may fix the wind vane with e.g. a piece of adhesive tape. When you have fixed the wind vane this way you can locate the reference point by aiming at it over the axis. Now you must turn the sensor casing on the mounting tube until the tip of the wind vane points to the reference point in the north.

To set up the sensor's north orientation select a landmark which is as far as possible up north with regard to the final position of the wind direction sensor.

The reference point can be selected using a topographical map (1:25000). The exact position of the reference point is determined using an amplitude compass that can be adjusted horizontally on a stand.



Please make sure there is no magnetic deviation of the compass.

When the north direction is set up for the wind direction sensor, you can mounting it as under point "Principle of installation". Remove any adhesive tape.

If you cannot select a northern reference point owing to local conditions, you can proceed analogously using a reference point in the south. In this case, however, you have to make sure the north mark on the sensor does not point to the reference point but in the opposite direction.



Electrical connection

The sensors are connected to a data measuring system via the open cable end (see drawing on the right side).

The connecting cable is suitably led along the mast between the data evaluation device (indicating instrument or data acquisition system) and the sensor. The cable must be fastened using appropriate cable ties (their length depends on the mast diameter).



Tip: Lead the cable in a wide curve from the mast to the bottom of the casing so that you can later easily dismount the cable.

Please make sure the cable is protected from humidity on the side of the data processing system. Generally, Pg sockets that use a rubber joint to prevent humidity from penetrating into the terminal box of the data processing system provide sufficient protection.



*Example representation:
Cable run by a EMC fair Pg-socket.*


Alternatively the lead can be laid also completely in the pipes of a mast, if the mast is accordingly prepared.



To reduce the risk of inductive interference the sensor must be properly grounded (screening on both sides).


Heating

The sensor disposes of an electronically controlled 18 W-heating within the sensor head. The heating is supplied together with the sensor electronics. (On request a separate supply of the sensor electronics and the heating by a fixed cable is possible.)



Under most climatological conditions the heating prevents blocking of the moving sensor parts (see illustration). The cup rotor or the wind vane are not heated. In case of icing or formation of ice at the moving sensor element the function is restricted for the period of icing.

Electrical connection





Technical data

Measuring principle:	Hall Sensor Array, non-contact
Range of application:	temperatures -40...+70 °C heated* · wind speed max. gusts 100 m/s · humidity 0...100 % r. h.
Supply voltage:	sensor 24 VDC (20...28 VDC) · 18 W-heating · max. 800 mA · The heating within the sensor head prevents blocking of the moving parts under most climatological conditions.
Housing:	seawater-resistant aluminium · IP 65 in upright position · M12 cable-plug connection · stainless steel nut and lock washer
Dimensions:	see dimensioned drawings
Included in delivery:	1 sensor · 15 m cable · with 4 pin M12 plug connector

Parameter Id-No.	Wind direction 00.14523.130 080	Wind speed 00.14524.100 080
Measuring element:	wind vane · aluminium · special surface	3-armed cup · aluminium · special surface
Measuring range:	0...360°	0.5...60 m/s
Accuracy:	± 2°	± 0.3 m/s ≤ 10 m/s; ± 0.5 m/s...60 m/s
Resolution:	< 1°	< 0.1 m/s
Starting value:	< 0.5 m/s	< 0.5 m/s
Output:	0...10 V = 0...360°	0...10 V = 0...60 m/s
Update rate:	4 Hz	4 Hz
Weight:	0.4 kg	0.35 kg

*) [Remark: In case of icing and formation of ice at the movable sensor measuring element the function is restricted for the period of icing. For installation sites with high risk of icing LAMBRECHT provides for specially heated sensors.]

Standards

- EMC acc. to EN 61000-6-2, EN 61000-6-4, EN 61000-4-2, -3, -4, -5, -6, -11, Namur NE-21
- VDE 0100
- WMO No. 8
- VDI 3786 part 2

Accessories (please order separately)

(14565 U17) Traverse	Id-No. 32.14565.017 000
(14567 U10) Traverse	Id-No. 32.14567.010 000
(14565 U19...) Lightning rod	Id-No. 32.14565.019 000



Quality System certified by DQS according to
DIN EN ISO 9001:2008 Reg. No. 003748 QM08

Subject to change without notice

PRO-WEA 0...10 V_b-e.indd 38.17

LAMBRECHT meteo GmbH
Friedlaender Weg 65-67
37085 Goettingen
Germany

Tel +49-(0)551-4958-0
Fax +49-(0)551-4958-312
E-Mail info@lambrecht.net
Internet www.lambrecht.net