



rain[e]observer

Complete system for measuring

- ▶ Amount of precipitation
- ▶ Precipitation intensity
- ▶ 16 types of precipitation

Features

- High-end solution for your precise measurements of precipitation quantity, intensity and 16 different types of precipitation (in accordance with WMO standard)
- The radar module of the rain[e]observer operates without moving parts and is therefore wear and tear-free
- Save time and money with easy installation and maintenance
- Plug & play upgrade set for the rain[e] series

rain[e] is the weighing precipitation sensor with its unique, self-draining collection system

rain[e] combines the highest resolution and precision in a very compact design



Table of Contents

1	General safety information	4
2	Warranty	4
3	Disposal	4
4	Introduction	5
5	Operating principle	5
6	Scope of delivery	5
7	Choosing the installation site	5
8	Connecting cables for rain[e] precipitation sensor and heating	6
9	Initial operation	7
9.1	General	7
9.2	Wiring the rain[e] as rain[e]observer · Internal connection diagram	8
9.2.1	Opening the housing	9
9.2.2	Changing the wiring	9
9.2.3	Closing the housing	9
9.3	Configuration of the rain[e] as a rain[e]observer	9
9.4	Installation of the rain[e] at the installation site	11
9.4.1	Choosing the installation site	11
9.4.2	Assembly	11
9.4.3	Integrated collection container	12
9.5	Installation of the observer module	15
9.6	Installing the mast mount for the traverse	16
9.7	Connecting the rain[e]observer - Connecting the system cabling	17
9.7.1	Connecting cables to the observer module and the rain[e]	17
9.7.2	Connection diagram	18
9.8	System start	18
10	rain[e]observer protocols	18
10.1	SDI-12 interface	18
11	Modbus protocol	27
11.1	Data encoding	27
11.2	Device address	28
11.3	Standard configuration - default	28
11.4	Modbus command set	28
11.5	Measured value and parameter register Lambrecht sensors	29
11.6	Special case of precipitation amount	30
11.7	Sensor status	30
11.8	Descriptive sensor parameter register (holding register)	31
11.9	Sensor parameters / configuration parameters	31
11.10	Autoconfiguration	32
11.11	Total amount of precipitation	32
11.12	Pulse output	32
12	Changing the communication protocol	32



13	<i>Changing the serial interface from SDI-12 (default) to RS485</i>	33
13.1	<i>Opening the housing</i>	33
13.2	<i>Change the device's internal wiring</i>	34
13.3	<i>Change the output protocol</i>	34
13.4	<i>Closing the housing</i>	35
14	<i>Checking and troubleshooting</i>	35
15	<i>Observer module maintenance</i>	36
16	<i>Storage and handling</i>	37
17	<i>Accessories and spare parts</i>	37
18	<i>Dimensions rain[e]observer</i>	38
19	<i>Connection cable (sensor / data logger)</i>	39
19.1	<i>Technical data connection cable</i>	39
19.2	<i>Connection cable drawings</i>	40
20	<i>Heating cable</i>	41
20.1	<i>Technical data heating cable</i>	41
20.2	<i>Heating cable drawings</i>	42
21	<i>Technical data, rain[e] precipitation sensors</i>	43
22	<i>Technical data observer installation set</i>	44
23	<i>Download of updates</i>	44



1 General safety information

The system is state-of-the-art and built in accordance with recognized safety regulations.

However, you should pay attention to the following information.

1. Before using the device, make yourself familiar with the relevant operating instructions.
2. Observe any in-house and country-specific guidelines and accident prevention regulations (e.g. from the employers' liability insurance). Obtain more information from your company safety officer, if necessary.
3. Use the system only in accordance with the purpose designated in the operating instructions.
4. Always keep the operating instructions close to hand wherever the system is used.
5. Operate the system only if it is in a technically flawless condition. You should immediately rectify any malfunctions that occur that may have an adverse effect on safety.
6. Do not allow any impermissible liquids to penetrate the inside of the measuring device.
7. You should take account of power surges and lightning protection as well as possibly appropriate grounding measures required in accordance with local regulations.

2 Warranty

Note the loss of warranty and exclusion of liability in the event of unauthorized access to the system. Changes to or interventions in system components may only be made with the explicit approval of **LAMBRECHT meteo GmbH** by qualified staff.

The warranty does not include

1. Mechanical damage due to external impact (e.g. falling ice, falling rocks, vandalism).
2. Effects or damage caused by power surges or electromagnetic fields that go beyond the standards and specifications referred to in the technical data.
3. Damage caused by improper handling, such as the use of incorrect tools, incorrect installation, incorrect electrical installation (reverse polarity) etc.
4. Damage that can be attributed to operation of the devices outside the specified conditions of use.

3 Disposal

Lambrecht Meteo GmbH is registered with the *Elektro-Altgeräte Register* (EAR Foundation) for waste electronic devices as follows.

WEEE-Reg.-Nr. DE 45445814

In the monitoring and control instrument category, type of device: Monitoring and control instruments for exclusively commercial use.

Within the EU



The device must be disposed of in accordance with European directives 2002/96/EC and 2003/108/EC (waste electrical and electronic devices). Waste devices must not be disposed of with household garbage. For environmentally friendly recycling and disposal of your waste device, please contact a certified disposal company for electronic waste.

Outside the EU

Please observe the regulations applicable to the proper disposal of waste electronic devices in each country.



4 Introduction

With the extension set described here and the electric module, in addition to the amount and intensity of precipitation, the rain[e] can use radar measurements to differentiate between 16 types of precipitation and thus becomes a rain[e]observer. These instructions describe the installation and commissioning of the rain[e]observer and the extension set.

5 Operating principle

The rain[e]observer's Doppler radar sends electromagnetic waves in the mW range upwards via a transmitting antenna array, i.e. towards the precipitation. The frequency used is internationally approved for measurements of this kind. The receiving antenna array of the sensor receives the signal reflected by the droplets or particles, from which the difference frequency between the two signals is determined.

The exact falling speed of the drops (particles) can be calculated from the difference frequency, which combined with the measurements taken for air temperature and humidity allows for 16 types of precipitation to be determined and differentiated approximately (see chart).

6 Scope of delivery

Scope of delivery for rain[e]observer installation set · ID no. 32.15184.300000

Note: rain[e] precipitation sensor not included (please order separately)

Item number	Designation
32.15184.200000	Detection of precipitation type (observer module)
32.15184.301000	Observer connection box
33.14627.001010	Aluminum profile 8 40x16 E 0.75 m
33.14627.002000	Mast mount
35.09331.540100	Hexagonal screw M8 x 16 DIN 933 A2
35.67981.500841	Serrated lock washer 8.4 DIN 6798 A A2
69.06500.590000	T nut 8 St M8, galvanized
69.61010.210000	Tension band
69.61010.210100	Turnbuckle

7 Choosing the installation site

To minimize possible spraying, it is recommended that you avoid locations with a hard floor surface (such as concrete) and to install the precipitation sensor instead on grass or another soft surface. In general, the sensor should not be placed on roofs or slopes.

In accordance with DWD standards, we recommend installing the precipitation sensor at a distance of at least 2 m or the obstacle height (above the sensor edge) to the next obstacle (such as trees or walls), twice the obstacle height in accordance with WMO standards or ideally four times the obstacle height.

Overgrowth by plants around the precipitation sensor must be regularly trimmed back to the height of the sensor in order to prevent the results being falsified and to reduce the effects of wind at the same time.

A specific point about the rain[e]observer's radar module is that there should be no large moving objects such as trees or cars driving within a radius of up to 10 meters in the module's field of vision. This applies in particular to moving objects at sensor height as well as gas disposal lamps (e.g. street lighting). The radar signals reflected from these objects could produce Doppler frequencies, which could be incorrectly interpreted as precipitation events.

You should take account of power surges and lightning protection as well as possibly appropriate grounding measures required on site in accordance with local regulations.

8 Connecting cables for rain[e] precipitation sensor and heating

To connect the rain[e] to a data collection device such as the PreLOG data logger, you require a connection cable with an M12 plug (ID no. 32.15184.060000). To power the heating you need a power cable (ID no. 32.15184.061000 or 32.15184.061010).

Connection cable for the sensor, 8-pin, M12 plug, length: 10 m	32.15184.060000
Connection cable for the heating, length: 1 m	32.15184.061000
Connection cable for the heating, length: 10 m	32.15184.061010



You should ensure that the external power connection for the heating is connected first – before the clamping plug for the heating in the device and the sensor connection. Otherwise the heating will be switched off during the automatic heating check.

The maximum possible distance between the rain[e] and the data collection device depends on the interface used.

- SDI-12 65...100 m, unshielded, low voltage cable
- RS485 1,000 m,
- Pulse output 1,000 m.

You can find further details of the respective cable lengths in the corresponding SDI-12 and RS485 standards.

$$P_a = \frac{U_N^4}{P_N \left(\frac{U_N^2}{P_N} + 2\rho \frac{l}{A} \right)^2}$$

If you use a power cable longer than the 1 m long cable we recommend to supply the heating, this formula gives you information about the actual power P_a at the nominal voltage $U_N = 24$ VDC, the nominal power $P_N = 140$ W, the specific electrical resistance $\rho = 0.017 \Omega \text{mm}^2/\text{m}$ for copper, the length of the cable l and the cross-sectional area of cable A .

The actual output should be $P_a > 125$ W in order to guarantee sufficient heating performance.

The USB cables for connections to the service interface (inside the **rain[e]**) should be no longer than 3 m.

Applies to **rain[e]H**: $P_a > 125$ W and $P_N = 140$ W; applies to **rain[e]400H** and **rain[e]314H**: $P_a > 187$ W and $P_N = 210$ W

9 Initial operation

9.1 General



There are different versions of the rain[e], which have already been prepared for the observer module upon delivery. With the rain[e] versions that are not prepared for the observer module, two additional installation steps have to be carried out first.

Essentially, the observer module can be connected to the following rain[e] models.



You can tell from the item number whether the rain[e] has been pre-wired and configured as standard for use as a rain[e]observer.

00.15184.XXX9XX



If there is an item number 9 at this point, the respective rain[e] model is directly prepared for connection of the observer module. (X = any number). Otherwise, the configuration of the 8-pin device plug must be wired in the precipitation sensor in accordance with the following connection diagram.


Installation involves the following steps.

1. Adapt the wiring of the 8-pin device plug in the rain[e] precipitation sensor *)
2. Configuration of the rain[e] as rain[e]observer with the rain[e] commander *)
3. Installation of the rain[e] at the installation site as required
4. Installation of the observer module
5. Plug in the system cabling
6. System start

*) These steps are omitted for the above-mentioned rain[e] sensors that have already been prepared for connecting the observer module.

9.2 Wiring the rain[e] as rain[e]observer · Internal connection diagram

If the observer module is retrofitted to a rain[e] precipitation sensor or if it is not supplied with a rain[e] prepared for the rain[e]observer, the configuration of the 8-pin device plug in the precipitation sensor must be wired in accordance with the following connection diagram.



It is important that the configuration of wires with the thick lines (WH, BN, GY, PK) is strictly adhered to. All other wires can be connected as desired.

Note: It is not possible to use the SDI-12 interface and the RS485 interface at the same time. To avoid malfunctions, it is recommended that only one of the two interfaces be connected to the plug connector internally. Communication via the SDI-12 interface is provided as standard; for the RS485 interface connection, see the section *Changing the serial interface from SDI-12 (default) to RS485*.

To change the wiring, open the housing.

9.2.1 Opening the housing

- Unscrew the knurled screw on the underside and turn the upper section counterclockwise in the direction of open. Carefully lift off the housing and pay attention to the connector for the heating inside the housing.



Please note that the measuring edge of the housing's upper section is very sharp. There is a risk of cuts. It is recommended that you do not press on the measuring edge and/or wear heavy-duty gloves.

- Pull out the clamping plug for the upper heating section and put the housing in a safe place. When putting the housing upper section aside, avoid placing it on the cutting edge of the receiver opening, in order not to damage it.

9.2.2 Changing the wiring

The wires are equipped with wire end sleeves and plug into push-in terminals. To loosen the wires, press the orange release button with a screwdriver (size 2) until the wire can be easily pulled out.

Based on the desired wiring scheme, place the loosened wires into the push-in terminals as far as they will go. It is not necessary to press the orange release button.

9.2.3 Closing the housing

1. Connect the clamping plug of the heating and position the upper housing section in such a way that the open/close sticker sits over the knurled screw.
2. Press the housing down and turn it clockwise in the direction of close.
3. Tighten the knurled screw.


9.3 Configuration of the rain[e] as a rain[e]observer


If this has not yet happened upon delivery, the rain[e] precipitation sensor must be reconfigured with the rain[e] commander in order to use the observer module.

Depending on the version, the rain[e] commander can be downloaded from the Lambrecht website or is included with the sensor upon delivery. For the configuration, the rain[e] does not have to be supplied with electricity but is fed via the service USB interface.



With the rain[e]H3 model, the USB interface only works if the external sensor supply is disconnected.

1. Connect the sensor using the supplied mini-USB on USB 2.0 cable to a PC, laptop or similar device on which the rain[e] commander has been installed and start the rain[e] commander. The observer module does not have to be connected for the configuration.
2. Select the used COM port of the USB interface (USB serial port).
3. Press the button  to load the current configuration for the rain[e].
4. For the "multipurpose" input, choose the precipitation type.



Setup - Version: 1.4.11 - Firmware Version: V1.56 v. 15.10.2020

COM Port: COM20 USB Serial Port

Product ID: 00.15184.000000 Hardware Rev.: 1.20

Serial Number: 851938.0007 Firmware: V1.56 v. 15.10.2020

Expert Configuration Quick Configuration

Pulse Output (not isolated)

Operating Mode: [Dropdown]

Closing Time (ms): 300 [Dropdown]

Resolution (mm): 0.10 [Dropdown]

Pulse Output (isolated)

Operating Mode: Pulse [Dropdown]

Closing Time (ms): 300 [Dropdown]

Resolution (mm): 0.03 [Dropdown]

Precipitation Event (not isolated)

Amount (mm): [Dropdown]

Start Time (s): 30 [Dropdown]

End Time (s): 90 [Dropdown]

Analog Output

Operating Mode: Deactivated [Dropdown]

Serial Port (RS485 / SDI12)

Operating Mode: SDI-12 [Dropdown]

Average Time (min): 10 [Dropdown]

SDI-12 Address: 0 [Dropdown]

Multipurpose Input

Function: [Dropdown menu open showing: Precipitation type, Reset analog output value, Deactivated, Precipitation type]

[Apply/Save button icon]

- If necessary, change the protocol that is to output the type of precipitation.



The precipitation type is only available in the SDI-12 extended protocol or the Modbus protocol. Other protocols can also be selected but these do not support the output of precipitation type. (For further details see the section on “*Protocols of the rain[e]observer*”).

- Send the new configuration to the rain[e] by pressing the button



9.4 Installation of the rain[e] at the installation site

9.4.1 Choosing the installation site

To minimize possible spraying, it is recommended that you avoid locations with a hard floor surface such as concrete and to install the precipitation sensor instead on grass or another soft surface. In general, the sensor should not be placed on roofs or slopes. In accordance with DWD standards, we recommend installing the precipitation sensor at a distance of at least 2 m or the obstacle height (above the sensor edge) to the next obstacle (such as trees or walls), twice the obstacle height in accordance with WMO standards or ideally four times the obstacle height.

Overgrowth by plants around the precipitation sensor must be regularly trimmed back to the height of the sensor in order to prevent the results being falsified and to reduce the effects of wind at the same time.

9.4.2 Assembly

Required tools

- ▶ Wrench (13 mm)
- ▶ Allen key (6 mm)
- ▶ Slotted screwdriver (approx. 2.5 blade width)


- Unpack the device.
- Take the box with the collecting container from the funnel of the **rain[e]**.
- Check the container for transport damage and place it back in the box until it is installed.

- Place the sensor on a pipe or mast with an outer diameter of 60 mm. If a wooden post is used, we recommend using an intermediate ring made of metal with a minimum length of 100 mm. Use the wrench (13 mm) to tighten the screws evenly on the base.



Avoid damage to the upper measuring edge.

- In order to improve operational safety at places at risk of lightning strikes, we recommend grounding the sensor with the **rain[e]**'s integrated earthing screw. The illustration shows the steps required to install the ground with a cable lug and an earthing screw on the sensor. The other end of the grounding cable should be connected with a peg.



9.4.3 Integrated collection container

Illustrations using the rain[e]



- Open the device
 - Unscrew the knurled screw on the underside.
 - Grasp the upper edge of the funnel and the mast shaft and turn the upper section counterclockwise (open).
 - Carefully lift off the housing - pay attention to the connector for the heating.




The housing upper section's measuring edge is very sharp. There is a risk of cuts. It is recommended that you do not press on the measuring edge and/or wear gloves.




Inner protective cylinder

Clamping plug for the heating


- Remove the clamping plug.
- Set the housing aside.
- Lift off the inner protective cylinder.



rain[e] inner workings without the collecting container



- Unpack the collecting container.
- Installing the collecting container
 - Press the collecting container with the magnetic side towards the reed contact against the bearing spring.
 - Insert the other side of the axle into the other side of the bearing.
 - **Make sure that the collecting container tilts properly.**




Use a spirit level to level the device by tightening the hexagonal screws evenly on the base.



- Reassembly
 - Carefully reinsert the inner protective cylinder.
 - Connect the clamping plug for the heating.
 - Place the housing back on the device – embossings into the recesses.
 - Press the housing down and turn it clockwise in the direction of close.
 - Tighten the knurled screw.
 - Insert the enclosed dirt trap into the funnel.



The housing upper section's measuring edge is very sharp. There is a risk of cuts. It is recommended that you do not press on the measuring edge and/or wear gloves.




- **Inserting the dirt trap**
Insert the enclosed dirt trap into the funnel. Try to hold the dirt trap in such a way that you can complete one whole anti-clockwise rotation and press the dirt trap into the funnel mouth as you twist it from above.
- **Removing the dirt trap**
Hold the dirt trap in such a way that you can complete one whole anti-clockwise rotation and pull the dirt trap upwards out of the funnel mouth as you twist it.

9.5 Installation of the observer module

Required tools

- Combination spanners or socket wrenches
 - o SW7 turnbuckle
(Optional slot 6.5 x 1.2)
 - o SW13 nut (mast)
- Allen key
 - o SW4 grub screw (traverse)




Pos.	Number	Component no.	Designation
1	1	32.15184.200000	Observer Modul
2	1	32.15184.301000	rain[observer] junction box
3	1	33.00001.072000	Nameplate WN1-72
4	1	33.14627.001010	Aluminium profile 8 40x16 E 0.75 m
5	1	33.14627.002000	Pole mount
6	4	35.09331.540100	Hexagon head screw M8 x 16 DIN 933 A2
7	4	35.67981.500841	Serrated lock washer 8.4 DIN 6798 A A2
8	2	67.04010.280000	Hose clamp TORRO W5 9mm 60-80
9	4	69.06500.590000	Slot nut 8 St M8, galvanized

9.6 Installing the mast mount for the traverse


Mast bracket assembly

Hold the mast bracket at the desired position of the mast in order to select the appropriate recess to guide the hose clamp, so that a good junction is created between the mast, mast bracket and hose clamp.


The hose clamps should be guided around the mast bracket and tightened with the turnbuckle on the back.




2. Mounting the angle bracket on the distribution box



3. Mounting the traverse on the mast bracket together with the distribution box




4. Mounting the observer module on the other end of the traverse




9.7 Connecting the rain[e]observer - Connecting the system cabling

9.7.1 Connecting cables to the observer module and the rain[e]



9.7.2 Connection diagram



9.8 System start

The entire rain[e]observer system starts automatically as soon as the sensor cable is connected. Once the system starts, an LED on the main circuit board of the precipitation sensor lights up for three seconds and then changes to rapid flashing during operation. The observer module shows a green light for about five minutes after the power supply is switched on. (Visible through the translucent housing.)

After ~15 seconds the rain[e] observer is ready to operate and starts by measuring and sending data to a connected data logger in accordance with the device configuration.

10 rain[e]observer protocols

This section only describes the protocols that also support output of the type of precipitation. You can find details about the other protocols supported by the rain[e] in the operating instructions of the rain[e] weighing precipitation sensor.

10.1 SDI-12 interface

Communication using the SDI-12 protocol via the SDI-12 interface is based on the *SDI-12 A Serial Digital Interface Standard for Microprocessor-Based Sensors, version 1.3, 2012*. The rain[e] can be used in bus operation parallel to other rain[e] devices.

The following subset of SDI-12 commands has been implemented in the rain[e]. For further information about the SDI-12 protocol, we refer you to the aforementioned standard documentation or the website www.SDI-12.org.



Implemented SDI-12 commands:

Command	Function	Sensor response
a!	Activity confirmation	a<CR><LF>
?!	Address query command	a<CR><LF>
aI!	Send identification	allccccccmmmmmmvvvxx...xx<CR><LF>
aAb!	Change address	b<CR><LF>
aM!	Start measurement	atttn<CR><LF>
aMC!	Start measurement with CRC	atttn<CR><LF>
aC!	Start parallel measurements	atttnn<CR><LF>
aCC!	Start parallel measurements with CRC	atttnn<CR><LF>
aD0! aD1!	Send data (buffer 0) Send data (buffer 1) If required with CRC	a<Werte><CR><LF> a<Werte><CRC><CR><LF>
aM1!	Generate variance	atttn<CR><LF>
aM2!	Generate heating data	atttn<CR><LF>
aM3!	Start measurement intensity (mean value, maximum and minimum)	atttn<CR><LF>
aMC1!	Generate variance with CRC	atttn<CR><LF>
aMC2!	Generate heating data with CRC	atttn<CR><LF>
aMC3!	Start measurement intensity (mean value, maximum and minimum) with CRC	atttn<CR><LF>
aC1!	Generate variance	atttnn<CR><LF>
aC2!	Generate heating data	atttnn<CR><LF>
aC3!	Start measurement intensity (mean value, maximum, minimum)	atttnn<CR><LF>
aCC1!	Generate variance with CRC	atttnn<CR><LF>
aCC2!	Generate heating data with CRC	atttnn<CR><LF>
aCC3!	Start measurement intensity (mean value, maximum, minimum) with CRC	atttnn<CR><LF>
aV!	Start verification	atttn<CR><LF>

a = Address of the corresponding sensor; standard sensor address = 0

SDI-12 commands always begin with the address of the corresponding sensor. All the other sensors on the same bus therefore ignore such commands. SDI-12 commands end with a !. All sensor responses also begin with the address of the sensor, but end with the ASCII characters for carriage return, <CR> and line feed, <LF>.

The SDI-12 protocol is based on the ASCII character set. The baud rate is 1,200 Bd and has the byte frame format:

- 1 Start bit
- 7 Data bits (least significant bit first)
- 1 Parity bit (even parity))
- 1 Stop bit

Activity conformation - a!

This command ensures the sensor is responding to inquiries. Essentially, it asks the sensor to confirm that it is connected to the bus.

The sensor responds with its address and the characters <CR><LF>.



Syntax

Command

Response

a!

a – Sensor address

! – Command end

a<CR><LF>

a – Sensor address

<CR><LF> – End of response

Example:

Command

Response

0!

0<CR><LF>

1!

1<CR><LF>

Send identification - aI!

The command **aI!** Requests the sensor to return its model number and firmware version.

Syntax

Command

Response

aI!

a – Sensor address

I – Command - Send identification

a 13LMGmbH1515184x1.0781129.0001<CR><LF>

a – Sensor address

13LMGmbH1515184x1.0781129.0001

13 – 2 characters SDI-12 version no.

13 = Version 1.3

LMGmbH15 – 8 characters manufacturer name

(= Lambrecht meteo GmbH)

15184x – 6 characters sensor type

(= **rain[e]** precipitation sensor)

1.0 – Sensor version (= version 1)

781129.0001 – 11 characters serial number

<CR><LF> – End of response

! – Command end

Beispiel:

Befehl

Antwort

0I!

013LMGmbH1515184x1.0781129.0001<CR><LF>

1I!

113LMGmbH1515184x1.0781129.0002<CR><LF>

Change address - aAb!

The factory setting for the address is **0**. If several sensors are connected to the same bus, the sensor address can be changed using the command **aAb!**. The address is always a single ASCII character. By default, the ASCII characters are used for the numbers between **0** and **9** (decimal 48 to 57). If more than 10 sensors are connected to a bus, the characters **A** to **Z** (decimal 65 to 90) and **a** to **z** (decimal 97 to 122) can also be used. The sensor responds with its new address and **<CR><LF>**. After the address has been changed, no further commands should be sent to the sensor for about a second. (see also *SDI-12 Standard, version 1.3, 2012*).



Syntax

Command	Response
aAb!	b<CR><LF>
a – Old sensor address	b – New sensor address
A – Command - Other address	
b – New sensor address	
! – Command end	<CR><LF> – End of responset

Example:

Command	Response
0A1!	1<CR><LF>

Start measurement - aM!

The **aM!** command requests the sensor to process the available measurement data and write it to an output string. Unlike standard sensors, as described in the SDI-12 documentation, the **rain[e]** measures continuously. As the string is generated, the recorded measurement values are loaded into a temporary buffer and are then processed upon completion of this event. Which is why the **rain[e]** always responds with **a003**. This is also the reason why the **rain[e]** does not send a **service request** and ignores commands to interrupt measuring. The connected data logger has to comply with the returned waiting time (3 seconds). When the waiting time is over, the data can be retrieved with the commands **aD0!** and **aD1!** (See below under **Send data**). The data are not overwritten until the next **C**, **M**, or **V** command and can be called up multiple times.

Syntax

Command	Response
aM!	a0036<CR><LF>
a – Sensor address	a – Sensor address
M – Command - Start measurement	003 – Seconds until the sensor returns the measurement data (= 3 s)
	06 – Number of measurement data
! – Command end	<CR><LF> – End of response

Example:

Command	Response
1M!	10036<CR><LF>

The measurement data can then be called up with the commands **aD0!** and **aD1!** (See below under **Send data**).



Start measurement with CRC - aMC!

The same command as **aM!** but the sensor also sends a 3-digit CRC checksum in addition to the prepared measurement data. For further information on generating this CRC checksum, we refer you to *SDI-12 Standard, version 1.3, 2012, section 4.4.12*.

Syntax

Command	Response
aMC!	a0036<CR><LF>
a – Sensor address	a – Sensor address
M – Command - Start measurement with CRC	003 – Seconds until the sensor returns the measurement data (= 3 s)
C – Request a CRC checksum to send	6 – Number of measurement data
! – End of command	<CR><LF> – Ende der Antwort

Example:

Command	Response
2MC!	20036<CR><LF>

Starte parallele Messung - aC!

With the **parallel measurement** the data logger can measure simultaneously with several **rain[e]** devices connected to the same bus.

The **aC!** command requests the sensor to process the available measurement data and write it to an output string. Unlike standard sensors, as described in the SDI-12 documentation, the **rain[e]** measures continuously. As the string is generated, the recorded measurement values are loaded into a temporary buffer and are then processed upon completion of this event. Which is why the **rain[e]** always responds with **a003**. This is also the reason why the **rain[e]** does not send a **service request** and ignores commands to interrupt measuring. The connected data logger has to comply with the returned waiting time (3 seconds). When the waiting time is over, the data can be retrieved with the commands **aD0!** and **aD1!** (See below under **Send data**).

The data are not overwritten until the next C, M, or V command and can be called up multiple times.

Syntax

Command	Response
aC!	a00306<CR><LF>
a – Sensor address	a – Sensor address
C – Command - Start parallel measurement	003 – Seconds until the sensor returns the measurement data (= 3 s)
! – Command end	6 – Number of measurement data
	<CR><LF> – End of response

Example:

Command	Response
2C!	200306<CR><LF>

The measurement data can then be called up with the commands **aD0!** and **aD1!** (See below under **Send data**).



Start parallel measurement with CRC - aCC!

The same command as **aC!** but the sensor also sends a 3-digit CRC checksum in addition to the prepared measurement data. For further information on generating this CRC checksum, we refer you to *SDI-12 Standard, version 1.3, 2012, section 4.4.12*.

Syntax

Command	Response
aCC! a – Sensor address C – Command - Start parallel measurement with CRC“ C – Request a CRC checksum to send ! – End of command	a00306<CR><LF> a – Sensor address 003 – Seconds until the sensor returns the measurement data (= 3 s) 06 – Number of measurement data <CR><LF> – End of response

Example:

Command	Response
2CC!	200306<CR><LF>



Send data - aD0! / aD1! / aD2! aD3! and D4! (SDI-12 extended)

In the following section, only the output of the measurement values in the SDI-12 extended protocol is described. The order of measured values in the buffers D0 and D1 corresponds to the Rain[e]'s original SDI-12 output, while the SDI-12 extended protocol provides information and readings in the buffers D2 and D3.

The type of precipitation code is output in buffer D4.

The data requested by the sensor with the commands C, M or V can be called up with the commands aD0! and aD1!. The sensor uses the corresponding prefixes (+ or -) as field separators. If the data has been requested with a CC or MC command, a CRC checksum is also returned. For further information on generating this CRC checksum, we refer you to *SDI-12 Standard, version 1.3, 2012, section 4.4.12*. The measurement data are output in metric units.



Due to hardware differences, some information about the rain[e]H3 is not available for the other rain[e] models. The corresponding fields are output as 0 and are marked as {rain[e] always 0} in the table below.

Command	Position	rain[e] / rain[e]H3
D0	1	Precipitation intensity of the last minute (mm/min)
	2	Precipitation intensity of the last minute (mm/h)
	3	Precipitation intensity since last access (mm/min)
D1	4	Precipitation intensity since last access (mm/h)
	5	Precipitation amount since last access (mm)
	6	Total precipitation amount (mm)
D2	7	Housing status (1 = open; 0 = closed) {rain[e] always 0}
	8	Error status Value from 0 to 255 is evaluated bit by bit Bit 0 Heating temperature error Bit 1 Heating test error Bit 2 Temperature sensor housing bottom error Bit 3 Temperature sensor funnel error Bit 4 RTC initialization error {rain[e] always 0} Bit 5 Temperature sensor outside error {rain[e] always 0} Bit 6 Power supply error Bit 7 Reserved
	9	Heating active (0 = no; 1 = yes)
	10	Operating hours {rain[e] always 0}
D3	11	Temperature of housing bottom (°C)
	12	Temperature of funnel (°C)
	13	Heating capacity (%)
D4	14	Precipitation type Synop code see <i>Precipitation codes by Synop</i> section (only with available observer module)



Synop-based precipitation codes

The following chart shows the keys of the recognizable types of precipitation based on the Synop table 4680, prohibitions and restrictions, volume D supplement 6 valid for automatic stations.

SYNOP keys w a w a	Meaning
0	No precipitation
40	Precipitation present
51	Light drizzle
52	Moderate drizzle
53	Heavy drizzle
61	Light rain
62	Moderate rain
63	Heavy rain
67	Light rain and/or drizzle with snow
68	Moderate rain and/or drizzle with snow
70	Snow
71	Light snow
72	Moderate snow
73	Heavy snow
74	Ice grains
89	Heavy hail
255	Error code

Syntax for measurements with aC! or aM! command

Command	Response
aD0! a – Sensor address D – Command - Send data 0 – Request for data from Buffer 0 or 1 = Buffer 1 ! – End of command	a<values><CR><LF> a – Sensor address <values> – Called up data separated by corresponding prefix (“+” or “-”) <CR><LF> – Ende der Antwort

Example:

Command	Response
0C!	000306<CR><LF>
0D0!	0+0.100+6.000+0.100<CR><LF>
0D1!	0+6.000+12.000+25.231<CR><LF>
.	
.	
.	



Syntax for measurements with aCC! or aMC!

Command

Response

aD0!

a – Sensor address
D – Command - Send data
0 – Request for data from
Buffer 0
or
1 = Buffer 1
! – End of command

a<values><CRC><CR><LF>

a – Sensor address
<values> – Called up data separated by
corresponding prefix (“+” or “-”)
<CRC> – 3-digit CRC checksum
<CR><LF> – End of response

Additional measuring options

The following commands can be used to request further measurement data from the **Rain[e]** and call up with **aD0!**.

The measurement commands **aMn!** and **aMCn!** have the same format as the commands **aM!** and **aMC!**. The same applies to the commands **aCn!** and **aCCn!**, which have the same format as the commands **aC!** and **aCC!**.

n	Function		Command	Response										
1	Creation of variance data (over 4 s)		aM1!	a0031<CR><LF>										
			aC1!	a00301<CR><LF>										
		with CRC checksum	aMC1!	a0031<CR><LF>										
			aCC1!	a00301<CR><LF>										
2	Creation of heating data <table><tr><th>Measurements</th><th>Unit</th></tr><tr><td colspan="2">Buffer 0</td></tr><tr><td>Temperature inside</td><td>°C</td></tr><tr><td>Heating ON (1) / OFF (0)</td><td></td></tr><tr><td>Total heating capacity</td><td>%</td></tr></table>	Measurements	Unit	Buffer 0		Temperature inside	°C	Heating ON (1) / OFF (0)		Total heating capacity	%		aM2!	a0033<CR><LF>
		Measurements	Unit											
		Buffer 0												
		Temperature inside	°C											
		Heating ON (1) / OFF (0)												
		Total heating capacity	%											
			aC2!	a00303<CR><LF>										
		with CRC checksum	aMC2!	a0033<CR><LF>										
aCC2!	a00303<CR><LF>													
3	Creation of data: mean precipitation intensity and max. and min. intensity of the last x minutes*. <table><tr><th>Measurements</th><th>Unit</th></tr><tr><td colspan="2">Buffer 0</td></tr><tr><td>Mean value of the last x minutes*</td><td>mm/min</td></tr><tr><td>Max. intensity of the last x minutes*</td><td>mm/min</td></tr><tr><td>Min. intensity of the last x minutes*</td><td>mm/min</td></tr></table> The standard value for the time x is 10 minutes. It can be changed using the rain[e] commander.	Measurements	Unit	Buffer 0		Mean value of the last x minutes*	mm/min	Max. intensity of the last x minutes*	mm/min	Min. intensity of the last x minutes*	mm/min		aM3!	a0033<CR><LF>
		Measurements	Unit											
		Buffer 0												
		Mean value of the last x minutes*	mm/min											
		Max. intensity of the last x minutes*	mm/min											
		Min. intensity of the last x minutes*	mm/min											
	aC3!	a00303<CR><LF>												
with CRC checksum	aMC3!	a0033<CR><LF>												
	aCC3!	a00303<CR><LF>												

* The recording of the data starts with transmission of the command. Call up must occur after exactly x minutes with the command **aD0!**.



Start verification - aV! (Error string)

The **aV!** command is used to carry out a system analysis for service purposes and to create an error string. It has the same format as the command **aM!** (see above). The **rain[e]** responds to it with **a0039**.

Syntax

Command	Response
aV!	a0039<CR><LF>
a – Sensor address	a – Sensor address
V – Command - Start verification	003 – Seconds until the sensor returns the measurement data (= 3 s)
	9 – Number of measurement data
! – Command end	<CR><LF> – End of response

Example

Command	Response
1V!	10039<CR><LF>

The measurement data can be called up using the command **aD0!** (See above under **Send data**).

Output data	Value range
Buffer 0	
Only for Lambrecht service	0...99
Error exceeding 10°C with heating on	0 or 1
Heating error	0 or 1
Temperature sensor error inside	0 or 1
Temperature sensor error on the funnel	0 or 1
Only for Lambrecht service	0 or 1
Only for Lambrecht service	0 or 1
Only for Lambrecht service	0 or 1
Only for Lambrecht service	0 or 1

+0 = ok; +1 = error

The data are not overwritten until the next **"C"**, **"M"**, or **"V"** command and can be called up multiple times.

Note on the SDI-12 Pause signal

As the **rain[e]** does not have any sleep mode, it does not have to be woken up from one. This means it ignores the **Pause** command. Therefore, restrictions that are associated with the **Pause** command do not have to be considered.

11 Modbus protocol

The Lambrecht meteo Modbus sensors and the met[LOG] follow the specification of the Modbus organization. Modbus Application Protocol Specification V1.1b3 (see www.modbus.org).

11.1 Data encoding

Modbus uses the "Big-Endian" format for addresses and data. This means that if a value is transmitted with a number format that is larger than a single byte, the most significant byte is sent first. With values that go beyond a register (e.g. 32 bit), this is not clearly specified at Modbus. The Lambrecht Modbus sensors follow the "Big-Endian" number format in these cases (32 bit or 64 bit).



Big-Endian example (1 register value):

16 bit value

0x1234 is transmitted in the order: 0x12 0x34.

Big-Endian example (2 register value):

32 bit value

0x12345678 is transmitted in the order: 0x12 0x34 0x56 0x78.

To obtain the actual measured value, divided the received register value by the divisor. Values of -9999 (16 bit value) or -9999999 (32 bit value) indicate an internal sensor error.

11.2 Device address

Modbus allows for the addresses 1...247.

11.3 Standard configuration - default

Baud rate: 19200 baud

Address: Each sensor type (or family) is given its own default address.

Default addresses of Lambrecht sensors:

Address	Sensor
1	Wind speed
2	Wind direction
3	Precipitation Rain[e]
4	THP
5	EOLOS IND · u[sonic]WS6
6	com[b]
7	PREOS
8	ARCO
9	u[sonic]
10	Pyranometer 2nd Class
11	Secondary standard pyranometer
12	PT100 to Modbus converter (temperature)
13	u[sonic]WS7

Byte frame in accordance with Modbus standard for RTU mode:

8E1 (1 start bit, 8 data bits, 1 parity bit (even parity), 1 stop bit)

11.4 Modbus command set

The Lambrecht Modbus sensors support the following commands.

- Read holding register command: 0x03 (descriptive sensor data register)
- Read input register command: 0x04 (measurement value register, each measured value to be requested individually)
- Write multiple register command: 0x10 (writing in configuration register)



11.5 Measured value and parameter register Lambrecht sensors

The register range 30001 to 35000 is provided for measured values in the Lambrecht sensors.

The following measured values are provided by the Rain[e] precipitation sensors.

Register	Parameter name	Unit	Divisor	Number of registers	Access type	
31001	Total precipitation amount (standard resolution)	mm	10	1	Read only	INT
31101	Total precipitation amount (high resolution)	mm	1000	2	Read only	LONG
31103	Precipitation amount since last access (high resolution)	mm	1000	2	Read only	LONG
31201	Precipitation intensity of the last minute (sliding)	mm/min	1000	1	Read only	INT
31301	Type of precipitation, code Only available with the rain[e] observer.	Open unit	1	1	Read only	INT
34901	Sensor status	-	1	1	Read only	INT
34921	Heating status	-	1	1	Read only	INT
34922	Internal temperature	°C	10	1	Read only	INT
34931	Total heating capacity in %	%	1	1	Read only	INT

The precipitation code in register 31301 is listed in the following table.

SYNOP keys w a w a	Meaning
0	No precipitation
40	Precipitation present
51	Light drizzle
52	Moderate drizzle
53	Heavy drizzle
61	Light rain
62	Moderate rain
63	Heavy rain
67	Light rain and/or drizzle with snow
68	Moderate rain and/or drizzle with snow
70	Snow
71	Light snow
72	Moderate snow
73	Heavy snow
74	Ice grains
89	Heavy hail



The following chart shows the keys of the recognizable types of precipitation based on the Synop table 4680, prohibitions and restrictions, volume D supplement 6 valid for automatic stations.

Register addresses 30001 to 35000 apply to all Lambrecht Meteo Modbus sensors, but are only present or valid if the respective sensor supports the corresponding values (e.g a pure wind sensor does not provide any air humidity). Lambrecht sensors return 0xD8F1=-9999(16 bit) or 0xFF676981=-9999999 (32 bit) as an error code or invalid value.

Example Total precipitation amount (standard resolution)

03	04	79	19	00	01	F8	B3	03	04	02	00	01	01	30
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

LEN 6	Transmission Query =>	Source Master	Dest Slave 3	Function Read Input Register (4)	Func Desk Address=31001, Quantity of Register=1	Checksum OK:B3F8	
LEN 5	Transmission Response <=	Source Slave 3	Dest Master	Function Read Input Register (4)	Func Desk Byte count=2	Data 00 01	Checksum OK:3001

Example Total precipitation amount (high resolution)

03	04	79	7D	00	02	F9	6D	03	04	04	00	00	00	91	19	E8
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

LEN 6	Transmission Query =>	Source Master	Dest Slave 3	Function Read Input Register (4)	Func Desk Address=31101, Quantity of Register=2	Checksum OK:6DF9	
LEN 7	Transmission Response <=	Source Slave 3	Dest Master	Function Read Input Register (4)	Func Desk Byte count=4	Data 00 00 00 91	Checksum OK:E819

11.6 Special case of precipitation amount

Except for the amount of precipitation, all the measured values should be read as instantaneous values. The amount of precipitation should be read as the total amount. And the difference from the previous access must be shown for the amount of precipitation displayed and to be saved.



The value overflow of the total precipitation must be taken into account when calculating the difference. The value overflow occurs at 60,000 g of collected liquid. This results in a value overflow at 3,000 mm for sensors with a collection area of 200 cm² and a value overflow at 1,500 mm for sensors with a collection area of 400 cm².

11.7 Sensor status

The sensor status can be called up via register 34901. The returned numerical value must be interpreted in binary as follows.

Bit position	Status message
0	1 = Error due to exceeding the maximum heating temperature
1	1 = Heating error
2	1 = Temperature sensor error inside
3	1 = Temperature sensor error on the funnel
4	1 = RTC initialization error
5	1 = Outside temperature sensor error (only rain[e]H3)
6	1 = Poor quality of power supply (only rain[e]H3)

11.8 Descriptive sensor parameter register (holding register)

Register	Parameter name	Number of registers	Note	Access type
40050	Device identification number (15 characters)	8 (2 characters in each register)	The returned data have the form of a 16 byte string with zero termination.	Read only
40100	Serial number (11 characters)	6 (2 characters in each register)	The returned data have the form of a 12 byte string with zero termination.	Read only
40150	Firmware version (up to 25 characters)	13 (2 characters in each register)	The returned data have the form of a 26 byte string with zero termination.	Read only

Example: Calling up the device identification number

(The identification number shown in the example is sensor-dependent. It is used here only for demonstration purposes).

															ASCII	
05	03	9C	72	00	08	CB	C3	05	03	10	30	30	2E	31	36	□□□□□□□□□□□□□□
34	38	30	2E	30	30	30	31	33	30	00	37	CA				00.16480.000130.□□

LEN 6	Transmission Query =>	Source Master	Dest Slave 5	Function Read Holding Register (3)	Func Desk Address=40050, Quantity of Register=8	Checksum OK:C3CB	
LEN 19	Transmission Response <=	Source Slave 5	Dest Master	Function Read Holding Register (3)	Func Desk Byte count=16	Data 30 30 2E 31 36 34 38 30 2E 30 30 30 31 33 30 00	Checksum OK:CA37

11.9 Sensor parameters / configuration parameters

Register	Parameter name	Allowed values	Number of registers	Access type
40001	Modbus address device		1	Write only
40200	Baud rate	96 = 9600 192 = 19200 384 = 38400	1	Write only
40201	Parity	1 = even 0 = none	1	Write only

The device must be restarted after any setting is changed.

Example Changing the RTU address from 3 to 1

03	10	9C	41	00	01	02	00	01	2D	E8	03	10	9C	41	00	01	7E	6F
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

LEN 9	Transmission Query =>	Source Master	Dest Slave 3	Function Write Multiple Register (16)	Func Desk Address=40001, Quantity=1	Byte count 2	Register values 00 01	Checksum OK:E82D
LEN 6	Transmission Response <=	Source Slave 3	Dest Master	Function Write Multiple Register (16)	Func Desk Address=40001, Quantity=1	Checksum OK:6F7E		



11.10 Autoconfiguration

All Lambrecht Modbus sensors provide the experienced user with the option of implementing auto-configuration in his Modbus master based on additional information stored in the sensor. The required information can be found in the document *General Instructions for Lambrecht Meteo Modbus Sensors*.

11.11 Total amount of precipitation

To measure the amount of precipitation from dataset to dataset using the serial protocols (e.g. SDI 12, Talker, Modbus), the difference between the total amount of precipitation and the previous reading must be calculated.



The value overflow of the total precipitation must be taken into account when calculating the difference. The value overflow occurs at 60000 g of collected liquid. This results in a value overflow at 3,000 mm for sensors with a collection area of 200 cm² and a value overflow at 1,500 mm for sensors with a collection area of 400 cm².

11.12 Pulse output

Each pulse corresponds to a predefined amount of measured precipitation. The rocker factor value range is 0.01...200 mm/pulse. The rocker factor can be set with the Rain[e] commander along with the closing time / pulse width. The pulse duty factor is 1:1, so the closing time is just as long as the pause time.

If more pulses have to be output than is possible with the set rocker factor and closing time, the excess pulses are placed in a queue and output as soon as no further pulses are added. If we now take the case that, for example, at a closing time of 200 ms, a rocker factor of 0.01 (corresponds to 300 pulses per minute) and a participation intensity of 4 mm/min over 2 minutes and then 1.9 mm/min (corresponds to 190 pulses per minute). Then the pulse output outputs 300 pulses in the first 2 minutes and 200 pulses are placed in the queue. In the third minute, 300 pulses are output again; 190 due to the current precipitation and 110 from the queue. Accordingly, 280 pulses are output in the fourth minute and 190 in all subsequent minutes. After the fourth minute, the pulses in the queue are completed.

12 Changing the communication protocol

See also the section *Configuration of the rain[e] as a rain[e]observer*.

For the configuration, the Rain[e] does not have to be supplied with electricity but is fed via the service USB interface.




With the rain[e]H3 model, the USB interface only works if the external sensor supply is disconnected.

1. Connect the sensor using the supplied mini-USB on USB 2.0 cable to a PC, laptop or similar device on which the rain[e] commander has been installed and start the rain[e] commander. The observer module does not have to be connected for the configuration.
2. Select the used COM port of the USB interface (USB serial port).



3. Press the button to load the current configuration for the rain[e].



4. Select the desired protocol in the operating mode field in the serial interface RS485/SDI-12 group.



The precipitation type is only available in the SDI-12 extended protocol or the Modbus protocol. Other protocols can also be selected but these do not support the output of precipitation type.

5. If necessary, you can change the operating mode in the pulse output isolated group. You can choose between pulses, rain yes/no and heating on/off.



The analog output and the non-isolated pulse output are not available in the standard configuration.

6. Send the new configuration to the Rain[e] by pressing the button



13 Changing the serial interface from SDI-12 (default) to RS485

The following steps are required to convert the interface used from SDI-12 to RS485.

1. Open the housing
2. Change the device's internal wiring
3. Change the output protocol
4. Close the housing

13.1 Opening the housing

- Unscrew the knurled screw on the underside and turn the upper section counterclockwise in the direction of open. Carefully lift off the housing and pay attention to the connector for the heating inside the housing.




Please note that the measuring edge of the housing's upper section is very sharp. There is a risk of cuts. It is recommended that you do not press on the measuring edge and/or wear heavy-duty gloves.

- Pull out the clamping plug for the upper heating section and put the housing in a safe place. When putting the housing upper section aside, avoid placing it on the cutting edge of the receiver opening, in order not to damage it.

13.2 Change the device's internal wiring

The following internal wiring is recommended.



To change the wiring, open the housing.

13.3 Change the output protocol



The precipitation type is only available in the SDI-12 extended protocol or the Modbus protocol.



The SDI-12 protocol can also be output via the RS485. Some data loggers on the market, such as the Ser[LOG], support this mode, which enables cable lengths of up to 1 km to be used for data transfer. Standard SDI-12 uses a signal to ground and is therefore limited to 65...100 m cable length. If disruptions in the communication occur, we recommend allowing communication via the RS485 interface, as long as the data logger (data collector) supports this function.

The usual communication settings apply to the SDI-12 protocol on the RS485 interface.

Baud rate: 1200 baud
Data bits: 7
Parity: even
Stop bits: 1

The following communication settings apply to the Modbus protocol.

Baud rate: 19200 baud
Data bits: 8
Parity: even
Stop bits: 1

Other protocols can also be selected but these do not support the output of precipitation type. For further details see the section *Protocols of the rain[e]observer*.

The changes to the output protocol are in accordance with the section *Changing the communication protocol*.

13.4 Closing the housing

1. Connect the clamping plug of the heating and position the upper housing section in such a way that the open/close sticker sits over the knurled screw.
2. Press the housing down and turn it clockwise in the direction of close.
3. Tighten the knurled screw.

14 Checking and troubleshooting

- Visual inspections for contamination should be carried out regularly - depending on the environment and seasonal influences (spider and bird populations, pollen, foliage, etc.). In accordance with section 6 of the *VDI guidelines - environmental meteorology - meteorological measurements - precipitation, VDI 3786 part 7 (December 2010)*, monthly inspections are recommended. In areas with high air pollution levels, weekly inspections may be necessary in order to ensure correct measurement results.



Please disconnect all external cables before you clean the inside of the sensor in order to avoid incorrect measurements. The funnel heating and drainage heating may get very hot if the heating is operated with the housing open. There is a risk of burns. It is therefore recommended that you unplug the heating supply connector when doing any cleaning or maintenance work.

- All parts exposed to water should be cleaned regularly. Rinsing with clean water should be enough to remove most of the dirt. Any dirt stuck in the collecting funnel or drainage system must be carefully removed. Slight soiling of the collecting container is not critical. The collecting container can be cleaned with water and a mild detergent.
- Make sure the device is stable and upright and check the bird deterrent ring, the sensor and especially the funnel surface for damage.
- Keep the measuring site free of overgrowing bushes and trees.
- The bird deterrent ring must be removed during periods of frost and snow.



Care should be taken when cleaning the collecting container in order to avoid damage. Do not clean the Rain[e] and the collecting container with a steel brush or similar devices or with aggressive cleaning agents.



Troubleshooting

The heating was switched off after the device was set up (error string: Heating error = 1)

- Disconnect the power supply to the sensor.
- Check that the power plug for the heating and the clamping plug for the funnel heating (inside the device) are connected.
- Reconnect the sensor to the power supply.

If the problem persists, it may be due to one of the following reasons.

- Drainage heating is not working or is not connected internally.
 - Funnel heating is not working.
 - Heating power cable is too long or defective.
- ⇒ In any case, please contact Lambrecht service.

Error message when calling up data from the rain[e] with the rain[e] commander.

Please disconnect the USB cable, reconnect it and restart the Rain[e] commander.

Rain[e] commander shows COM port not found or rain[e] is not responding.

- Check whether the rain[e] is connected correctly to the PC and the correct COM interface has been selected.
- If the problem persists, restart the rain[e].

The system always outputs 0 for the type of precipitation.

Check the connections of the observer module and the distribution box. Are the observer module and the rain[e] properly connected?

15 Observer module maintenance

As the precipitation detector operates without moving parts, i.e. wear and tear-free, only minimal service work is required.

Depending on its location, the device may become dirty. Cleaning should be carried out with non-aggressive cleaning agents, water and a soft cloth.



The surface of the device cover has been roughened for technical measurement reasons and must not be polished under any circumstances. When cleaning the cover, please ensure that you use only soft cloths or brushes without any polishing effect and a grease-dissolving cleaning agent (washing-up liquid, no aggressive solvents such as acetone).

During storage, assembly, dismantling, transport or maintenance of the precipitation detector, you should ensure that no water gets inside the device and the plug. The cover surface should not be touched with the palms of hands or fingers, in order to avoid contamination with sebaceous matter.



Attention: Do NOT clean the housing cover with a microfiber cloth.

If you need help with solving any problems that may occur, please contact Lambrecht meteo service at

Tel +49-(0)551-4958-0
E-mail support@lambrecht.net



16 Storage and handling

The rain[e]observer should be stored in its original packaging in a dry place (relative humidity < 60 %) and at moderate temperatures (5...25 °C).



The storage temperature range specified in the technical data should not fall below or exceed this. The rain[e]observer must be transported in its original packaging.

17 Accessories and spare parts

General accessories

32.15184.060 000	Connection cable with M12 plug (sensor data logger); L = 10 m (8-wire)
65.53090.160 100	USB cable (sensor configuration)
36.15184.000 000	rain[e] commander
00.15180.400 000	Stainless steel mast for concrete foundation
00.15180.800 050	Stainless steel mast for concrete foundation with base plate
32.15180.022 020	Bird deterrent ring for rain[e]H3
32.15180.022 040	Bird deterrent ring for rain[e]400 and rain[e]314
32.15180.023 020	Bird deterrent ring for rain[e]
33.15189.049 010	Dirt trap (replacement part)
32.15184.080 000	Maintenance set



For heated versions

00.14966.200 000	Power supply 150 W · not for rain[e]400H and rain[e]400H
00.14966.500 000	Power supply 240 W for rain[e]400H and rain[e]314H
32.15184.061 000	Connection cable (heating) for mounting on mast; L ≈ 1 m (4-wire)
32.15184.061 010	Connection cable (heating) for mounting on mast; L ≈ 10 m (4-wire), T-coded
32.14622.220 000	Mast bracket for power supply

Services

97.15180.000 000	Customer-specific configuration
------------------	---------------------------------

18 Dimensions rain[e]observer






19 Connection cable (sensor / data logger)

19.1 Technical data connection cable

Connection cable	ID no. 32.15184.060000
General data	
Rated current at 40°C	2 A
Rated voltage	30 V AC
Number of terminals	8
Contact resistance	≤ 5 mΩ
Insulation resistance	≥ 100 MΩ
Cable length	10 m
General characteristics	
Standards/regulations	M12 connector IEC 61076-2-101
Coding	A - standard
Protection type	IP65/IP67
Cycle of operation	≥ 100
Material	
Material contact	CuZn
Material contact surface	Ni/Au
Material carrier material	TPU GF
Material handle body	TPU, flame retardant, self-extinguishing
Knurl material	Die-cast zinc, nickel-plated
Material seal	NBR
Line	
Cable type	PUR halogen-free black
Conductor cross-section	8x 0.25 mm ² (signal line)
AWG signal line	24
Cable outer diameter D	5.9 mm ± 0.2 mm
Wire colors	Brown, white, green, yellow, gray, pink, blue, red
Insulation resistance	≥ 1 GΩ*km (at 20 °C)
Conductor resistance	≤ 78 Ω/km (at 20 °C)
Nominal voltage line	≤ 300 V
Test voltage line	≥ 3000 V AC (spark test)
Cable weight	53 kg/km
Minimum bending radius, permanently laid	5 x D
Flame resistance	In accordance with UL FT-2 In accordance with UL 758/1581 (horizontal) In accordance with UL 758/1581 FT2 In accordance with DIN EN 60332-2-2 (20 s)
Halogen-free	In accordance with DIN VDE 0472 part 815 In accordance with IEC 60754-1
Oil resistance	In accordance with IEC 60811-2-1
Other resistance	Good resistance to acids, alkalis and solvents Resistant to hydrolysis and microbes


19.2 Connection cable drawings

Schematic representation



Pin assignment M 12 socket, 8-pin, A-coded, socket side view

Circuit diagram



Contact assignment of the M12 socket

Dimensional drawing



M12 x 1 socket straight, shielded




20 Heating cable

20.1 Technical data heating cable


Heating cable	ID no. 32.15184.061010 (length = 10 m) ID no. 32.15184.061000 (length = 1 m)
Environmental conditions	
Protection type	IP65/IP67
General	
Rated current at 40°C	12 A
Rated voltage	63 V DC
Rated impulse voltage	1.5 kV
Number of terminals	4
Insulation resistance	≥ 100 MΩ
Coding	T power
Cycle of operation	> 100
Material	
Flammability class in accordance with UL 94	V0
Material contact	CuZn
Material contact surface	Ni/Au
Material carrier material	PA
Material handle body	PP
Knurl material	Die-cast zinc, nickel-plated
Line	
Cable type	PUR halogen-free black
Conductor cross-section	4x 1.5 mm ²
AWG power supply	16
Cable outer diameter D	9.7 mm ± 0.3 mm
Wire colors	Brown, white, blue, black
Insulation resistance	≥ 10 MΩ*km (at 20 °C)
Conductor resistance	≤ 13.3 Ω/km (at 20 °C)
Nominal voltage line	300 V AC
Test voltage line	1500 V AC (5 min.)
Flame resistance	In accordance with EN 60332-1-2 In accordance with UL 1581 VW1
Halogen-free	In accordance with DIN VDE 0472 part 815 In accordance with IEC 60754-1
Oil resistance	In accordance with DIN EN 60811-2-1 In accordance with DIN EN 50363-10-2

20.2 Heating cable drawings


Schematic representation



Circuit diagram



Dimensional drawing




21 Technical data, rain[e] precipitation sensors

	rain[e] heated, preconfigured	rain[e]314 heated, preconfigured	rain[e]400 heated, preconfigured	rain[e]H3 heated, preconfigured
ID no.	00.15184.400900	00.15184.403900	00.15184.404900	00.15184.540920
Measurable precipitation types	Liquid, solid, mixed			
Measuring principle	Weighing, with automatic self-draining			
Operating temperature	-40...+70°C *)			
Storage temperature	-40...+70°C			
Catchment area	200 cm²	314 cm²	400 cm²	200 cm²
Measuring range (amount)	Without limitation (0.005...∞ mm)	Without limitation (0.0032...∞ mm)	Without limitation (0.0025...∞ mm)	Without limitation (0.005...∞ mm)
Liquidation (amount)	0.001 mm (pulse output: 0.01 mm)			0.001 mm
Accuracy (amount)	0.1 mm or 1% at < 6 mm/min and 2% at ≥ 6 mm/min	0.1 mm or 1% at < 3.82 mm/min and 2% at ≥ 3.82 mm/min	0.1 mm or 1% at < 3 mm/min and 2% at ≥ 3 mm/min	0.1 mm or 1% at < 6 mm/min and 2% at ≥ 6 mm/min
Measuring range (intensity)	0...20 mm/min or 0...1,200 mm/h	0...12 mm/min or 0...720 mm/h	0...10 mm/min or 0...600 mm/h	0...20 mm/min or 0...1,200 mm/h
Liquidity (intensity)	0.001 mm/min or 0.001 mm/h			
Accuracy (intensity)	0.1 mm/min or 6 mm/h			
Measurement value output	SDI-12 • Modbus RTU • Pulse output			
Plugs	8-pin M12 (sensor)· 4-pin T-coded (heating)			8-pin M12 (sensor) · 4-pin T-coded (heating) · 4-pin D-coded (Ethernet)
Measurements	292 mm x 190 mm (H x D)	311 mm x 256 mm (H x D)	311 mm x 256 mm (H x D)	377 mm x 190 mm (H x D)
Mountable on	Mounting mast Ø 60 mm			
Weight	Approx. 2.5 kg	Approx. 4 kg	Approx. 4 kg	Approx. 4 kg
Standards	WMO no. 8 • VDI 3786 Bl. 7 • EN 61000-2, -4 • EN 61000-4-2, -3, -4, -5, -6, -11 • Namur NE-21			
Protection class load cell	IP67			
Power consumption	Max. 45 mA at 24 V supply and analog output • typical 7.5 mA at 24 V supply and pulse output • typical 12.5 mA at 12 V			max. 45 mA at 24 V supply and analog output • typical 12.5 mA at 24 V • max. 150 mA at 12 V supply over Ethernet
Power supply voltage	9.8... 30 V			
Heating				
Heating data	Electronically controlled, 2 heating circuits			Electronically controlled, 3 heating circuits: Ring, funnel and drainage heating
Target temperature	+2°C funnel surface temperature			
Accuracy	± 1°C			
Heating capacity	80 W (funnel) · 60 W (drainage / collection container)	150 W (funnel) · 60 W (drainage / collection container)	150 W (funnel) · 60 W (drainage / collection container)	70 W (funnel) · 60 W (drainage / collection container)· 70 W Ring heating
Power supply voltage	24 VDC / 140 W	24 VDC / 210 W	24 VDC / 210 W	24 VDC / 200 W

- Pulse output 1 (galvanically separated, open collector): Max. 24 V DC / max. 0.05 A / max. 0.5 W
- Pulse output 2 (open collector): Max. 24 V DC / max. 0.1 A / max. 0.5 W

22 Technical data observer installation set

ID no.	32.15184.300000
Measurement range	See Synop code table
Power current characteristics	In addition to the rain[e] 14 mA at 24 V; max. 25 W in heating mode
Area of application	-40...70 °C (heated, no icing, no snow drifting)
Storage conditions	-55...+80 °C
Protection type	IP65 / IP67
Materials	<ul style="list-style-type: none"> • V4A tab • Cover made of PC (polycarbonate – UV stabilized) • Aluminum base plate, anodized • ASA slats
Weight	0.64 kg
Mounting type	Tab to mount on system traverse. The traverse can be fastened to pipes of up to 80 mm diameter.



23 Download of updates

On our website (<https://www.lambrecht.net>) you can find free software tools and firmware under *Support* in the software portal. You can find the latest software for our products here. Simply select the relevant software from the respective menus.

After downloading, you can benefit from new features and product extensions from Lambrecht meteo development.