

Firmware Update Ser[LOG]

The update of the firmware in Ser[LOG] is carried out with a USB stick.

Ser[LOG] will show the version of firmware being used on the display, after activation of the control unit (press the rotary button).

The firmware will be sent via e-mail. It consists of a file named "sl".
Please copy this file in to the root directory of your USB stick (e.g. "E:\\" => "E:\sl").

Please activate the Ser[LOG] control unit (by pressing the turn/push button).
Please make a note of the date shown on the display.

Turn the turn/push button until the menu "Firmware Update" appears.

Please press the turn/push button. This brings up the menu "Enter Password".
The password for loading the firmware is the date of Ser[LOG] (see above.) in the format YYMMDD (17 February 2010 => "100217").
Enter the password digit by digit.
After entering the valid password, the prompt "Insert USB Stick" will appear.

Please place the USB stick in the Ser[LOG] host adapter.
Ser[LOG] will read the firmware file and check it for errors.
If the file is alright, the menu "V1.xxx -> V1.xxx" "y/n left/right" will appear.
Turn the turn/push button one notch to the left.

The firmware is updated.

Ser[LOG] restarts.
The current firmware will be shown on the display.